

ZOOM ADSL X6 (lights on top)




Light 1: Power: Should be green and solid

Light 2: DSL: Should be green and solid

Light 3: Internet: Should be green and blinking as data is transferred. If the light is red, modem has lost its settings; please call our office for assistance.

Ethernet Lights (1-4): Should be green and blinking as data is transferred for each device plugged in.

Light 5: WLAN: Should be green and blinking as data is transferred



- Ethernet cable (blue in this picture) goes from one of the 4 ports to your computer/device.
- Base cord (gray in this picture) goes from single DSL port the DSL jack on the wall.
- Black cord is for power